

AS 33, AS 34, AS 40

Actuating the door opener

Door call **R** * 1 1 Internal phone number of the door

Direct * 1 2 Internal phone number of the door

Activating diversion from (follow me)

* 5 7 1

Deactivating diversion from (follow me)

* 5 7 0

Activating diversion to (diversion by the telephone system)

* 5 8 1=permanent 2=on busy 3=if no answer Destination: 1=external 2=internal 3=abbreviated dialling Diverted internal phone number External phone number or phonebook number **#**

Deactivating diversion to (diversion by the telephone system)

* 5 8 0 Diverted internal phone number

Diversion to - call forwarding (diversion by the ISDN exchange)

Permanent * 6 3 Destination: 1 = external phone number 2 = phonebook number Diversion: Enter the system or multiple subscriber number **#** Destination: Enter the external phone number or phonebook number **#**

on busy * 6 4 **#**

if no answer * 6 5 **#**

deactivating * 6 3 0 system or multiple subscriber number **#**

Activating/deactivating timers

* 1 3 Timer group 0 = Timer off 1 = Timer on 2 = Funktion off 3 = Funktion and timer on

Notes: On telephones, particularly telephones that use the pulse dialling method that do not have a * key or which do not support these functions, you must press the digits 99 instead of the * key.

Ident. No. 523 704

Modifications and errors reserved

Printed in Germany 1992

AGFEO GmbH & Co. KG

Gaswerkstr. 8

D-33647 Bielefeld

Internet: <http://www.agfeo.de>

Short-form operating instructions for analog and ISDN terminals

External call

Dial "0" to seize an outside line 0 Spontaneous outside line seizure with internal

External call and seizing a specific MSN (instead of seizure with "0")

* 0 0 External phone number(MSN) **#**

Reserving an outside line (B channel) (seizure with "0")

0 **R** * 2 9

Internal call

Dial "0" to seize an outside line Spontaneous outside line seizure with internal **#**

Internal phone number - 11 to 99 depending on the decade

Internal forwarding without announcement

R

External forwarding

R 0 **R** * 2 0

Answering a waiting call / Rejecting a waiting call

R * 8 **R** * 2 1

Internal call waiting announcement

R * 1 9

Call waiting prevention on/off

* 5 5 1 = on 0 = off 1 = 1st internal phone number 2 = 2nd internal phone number 0 = both internal phone number

Picking up an answering machine call

Internal number of the answering machine

Picking up calls

External call Selective call pick-up Internal phone number

Do not disturb

1 = 1st internal phone number
2 = 2nd internal phone number
0 = both internal phone number 1 = internal calls
2 = external calls
3 = all calls
4 = Do not disturb off

Call variant 2 (night service)

1 = on
0 = off
2 = all off
3 = all on Phone number of call variant 2

Call variant 3 (internal call forwarding)

1 = on
0 = off
2 = all off
3 = all on Phone number of call variant 3

Automatic dialling - connection without dialling

1 = on
0 = off

Busy on busy

1 = on
0 = off External phone number

Three-party conference (internal/external)

ISDN three-party conference

Announcement to system telephones

Internal phone number of a system telephone
00 = to all system telephones

Placing a connection on hold (point-to-multipoint connection only)

Least Cost Routing (LCR) on/off

1 = on
0 = off

Parking in the telephone system

Unparking

Room monitoring

preparing Pick up Enter the guarding telephone's internal phone number

Relay switching

Internal phone number 1 = on
0 = off

Inquiry / brokering

Return to external subscriber with "0" to external subscriber with internal phone number to an internal call ...

Call back on busy (ISDN)

Initiating an internal callback

Dialling a phonebook number

to

Telephone lock

1 = lock
0 = unlock Telephone code

Door call diversion on

1 = external phone number
3 = phonebook number Internal phone number of the door External phone number or phonebook number

Door call diversion off

Internal phone number of the door

Door call variant 2 (night service)

1 = on
0 = off Internal phone number of the door

Calling a door station / picking up a door call

Internal phone number of the door